



CP9449 DRIVER INSTALLATION INSTRUCTIONS

- 1) Plug the tool into an available USB Port, power the tool on, and put the tool in program mode. (See user manual for program mode instructions.)

Note: If the Windows "New Hardware Wizard" is already open, skip to step 5. Otherwise, proceed to step 2.

WINDOWS ME:

- 2) Open Windows **Control Panel** and *double-click* on the **System** icon.
- 3) Click on **Device Manager**.

WINDOWS XP:

- 2) *Right-click* on your **my computer** icon and select **manage** from the drop down list.
- 3) In the left-hand side of the Computer Management window, click on **device manager**.
- 4) In the right-hand column, *double-click* on **USB Device** and click on **Reinstall/Update Driver**. This should be located under the **Other Devices** icon.

**There is usually a yellow question mark or exclamation mark next to the icon and it is usually located under the "Other Devices" folder. If you have trouble locating the icon, reensure that your tool is plugged in and powered on.

- 5) Highlight the bullet next to **install from a list or specific location (advanced)** and click **next**.
- 6) Highlight the bullet next to **search for the best driver in these locations**:
- 7) Check the box next to **Include this location in the search**.
- 8) Click the **browse** button.
- 9) Browse for **C:\Program Files\ScanningSuite\ABSUpdate\Drivers** and click **OK**.
- 10) Click **next**.
- 11) The Found New Hardware Wizard will begin searching for the USB Cable Driver.

A Windows warning might appear stating "The software you're installing for this hardware: SPX USB device has not passed windows logo testing to verify it's compatibility with windows XP." The software has been tested by the company and is compatible so click "continue anyway**."

- 12) When the files are done downloading click **finish**.

Your drivers are now installed and you can continue with Scanning Suite operation.